

SHORT CUTS




LOLUX 24V & 230V
FAST 24

IMPORTANT

CHANGE GATE DIRECTION

Factory settings close the gate from left to right.

Factory setting



To change direction:

1. Power Up. The screen shows '---'.
2. To change direction close right to left:
Scroll to **P063**, press **OK**. Scroll to **d001**.
Press **OK**
3. Change limit switch orientation:
Scroll to P021, press OK. Scroll to d014.
Press OK
Scroll to P022, press OK. Scroll to d012.
Press OK
4. Scroll to '---'.

